

HORIZONE

Touch Screen
VS05HxxWEB - VS08HxxWEB

QUICK START GUIDE

INSTALLAZIONE

1. Installare la scatola da incasso a muro, in base al modello di dispositivo (Vedere SCATOLE E DIMENSIONI)
2. Applicare la cornice in dotazione sopra la scatola a muro
3. L'alimentazione avviene tramite POE (Power Over Ethernet).
4. In assenza di uno switch POE, prevedere un POE INJECTOR
5. Collegare la rete al touch Horizone e fissarlo a parete, utilizzando le viti laterali per vincolarlo alla cornice

CONFIGURAZIONE

Per modificare la schermata principale utilizzare l'icona a forma di matita in alto a destra. I PIN di default sono "9999" per l'Amministratore e "1234" per l'Utente (modificabili).

Per aggiungere una applicazione al menu, premere "+" in alto, selezionare una app tra quelle disponibili, scegliere l'icona ed inserire la descrizione.


Tramite pulsante di configurazione, in alto a sinistra, è possibile accedere alle seguenti impostazioni:

1. "PIN Amministratore" e "PIN Utente": mostra il PIN attuale e permette di modificarlo;
2. "Selezione background": permette di selezionare lo sfondo della pagina principale
3. "Non visualizzare logo": permette di scegliere se visualizzare o meno il logo Electron nella schermata principale
4. "Impostazioni Android": permette di accedere alle impostazioni del sistema operativo
5. "Configurazioni rete": configura i parametri di rete LAN, potendo impostare un indirizzamento statico (il dispositivo opera in DHCP di predefinito)
6. "Aggiornamento Firmware": permette di aggiornare il firmware del dispositivo, se disponibile tramite internet
7. "Timer spegnimento schermo": permette di configurare un tempo dopo cui spegnere lo schermo se inutilizzato;
8. "Reboot del dispositivo": riavvia il dispositivo
9. "Esci dall'App": permette di uscire dall'ambiente menu, e passare all'ambiente grafico del sistema operativo, ad esempio per installare nuove applicazioni.

ATTENZIONE: si sconsiglia di modificare il valore predefinito di luminosità dello schermo (40%), onde evitare il danneggiamento del dispositivo. Si consiglia inoltre di attivare lo spegnimento del display dopo un tempo non superiore ai 60 secondi, per prolungare la vita operativa del pannello.

CONFIGURAZIONE HORIZONE TOUCH SCREEN

Per accedere ad Horizone da Horizone Touch Screen, aprire la app "Horizone" e configurarla come nella figura di esempio sottostante:



Assicurarsi in particolare di:

1. selezionare "Zyk" come rete di casa;
2. inserire l'indirizzo IP di Horizone anche nelle impostazioni remote;
3. deselectare l'HTTPS nelle impostazioni remote.

SCATOLE E DIMENSIONI

	VS05HxxWEB	VS08HxxWEB
Ingombro	81x132x14	224x149x16
Scatola	Scatola da incasso 2M (es: BTicino 502E) Scatola tonda d.60 (es: Gewiss 24232)	Scatola da incasso BTicino 16204 Scatola da incasso 3M (es: BTicino 503E) nello stesso verso di montaggio

ULTERIORI INFORMAZIONI

Per uso domestico solo in interni.
L'apparato richiede alimentazione costante e non va inteso come dispositivo di sicurezza.




Per ulteriori informazioni visitare: www.electron.com

Electron spa

Via Monteverdi 6
I-20025 Legnano (MI) - Italia
Tel: +39 0331 500802 Fax: +39 0331 564826
Email:info@electron.com Web: www.electron.com



DIAGRAMMA DI CONNESSIONE





HORIZONE

Touch Screen

VS05HxxWEB - VS08HxxWEB

QUICK START GUIDE

INSTALLATION

1. Install the flush-mounted box, according to the device model (See BOXES AND DIMENSIONS)
2. Apply the supplied frame over the wall box
3. Power is supplied via POE (Power Over Ethernet).
4. If a POE switch is not available, provide a POE INJECTOR
5. Connect the net to the Horizone touch and fix it to the wall, using the lateral screws to secure it to the frame

CONFIGURATION

To change the main screen use the pencil icon in the upper right corner. The default PIN are "9999" for the Administrator and "1234" for the User.

To add an application to the menu, press the symbol "+" at the top, select an app from those available, choose an icon and type the description.

Through the configuration button, at the top left, you can access the following settings:

6. "Administrator PIN" and "User PIN": shows the current PIN and allows you to change it;
7. "Select background": allows you to select the background of the main page
8. "Do not display logo": allows you to choose whether or not to display the Electron logo on the main screen
9. "Android Settings": allows you to access the operating system settings
10. "Network configurations": configures the LAN network parameters, being able to set a static addressing (by default the device operates in DHCP mode)
11. "Firmware Update": allows you to update the firmware of the device, if available via the Internet
12. "Screen off timer": allows you to configure a time after which to turn off the screen when device is not used;
13. "Reboot device": reboot the device
14. "Exit the App": allows you to exit the menu environment, and switch to the graphic environment of the operating system, for example to install new applications.

ATTENTION: it is recommended to not change the default value of screen brightness (40%), in order to avoid damaging the device. It is also advisable to turn the display off automatically after a time not exceeding 60 seconds, to extend the operating life of the panel.

To access Horizone web services from the Horizone Touch Screen, open the "Horizone" app and configure it as in the example figure below:

In particular, be sure to:

1. select "Zyk" as home network;
2. enter the IP address of Horizone also in the remote settings;
3. Deselect HTTPS in remote settings.

BOXES AND DIMENSIONS

	VS05HxxWEB	VS08HxxWEB
Dimensions	81x132x14	224x149x16
Mounting box	Inwall box 2M (ex: BTicino 502E) Round box Ø60 (ex: Gewiss 24232)	Inwall box BTicino 16204 Inwall box 3M (ex: BTicino 503E) same mounting direction

FURTHER INFORMATION

For indoors domestic use only. The apparatus requires constant power supply and is not intended as a safety device.



For further information please visit www.electron.com

Electron spa

Via Monteverdi 6
I-20025 Legnano (MI) - Italia
Tel: +39 0331 500802 Fax: +39 0331 564826
Email:info@electron.com Web: www.electron.com



WIRING DIAGRAM

