


A

N*	Abilitato	Descrizione	1	2	3	4	5	6	7	8	Seriale
01	<input type="checkbox"/>	RADIOCOMANDO 001									
02	<input type="checkbox"/>	RADIOCOMANDO 002									
03	<input type="checkbox"/>	RADIOCOMANDO 003									
04	<input type="checkbox"/>	RADIOCOMANDO 004									
05	<input type="checkbox"/>	RADIOCOMANDO 005									
06	<input type="checkbox"/>	RADIOCOMANDO 006									
07	<input type="checkbox"/>	RADIOCOMANDO 007									
08	<input type="checkbox"/>	RADIOCOMANDO 008									
09	<input type="checkbox"/>	RADIOCOMANDO 009									
10	<input type="checkbox"/>	RADIOCOMANDO 010									
11	<input type="checkbox"/>	RADIOCOMANDO 011									
12	<input type="checkbox"/>	RADIOCOMANDO 012									
13	<input type="checkbox"/>	RADIOCOMANDO 013									
14	<input type="checkbox"/>	RADIOCOMANDO 014									
15	<input type="checkbox"/>	RADIOCOMANDO 015									
16	<input type="checkbox"/>	RADIOCOMANDO 016									

B

**ITALIANO****Avvertenze generali**

⚠ Importanti istruzioni per la sicurezza delle persone:
LEGGERE ATTENTAMENTE!

- L'installazione, la programmazione, la messa in servizio e la manutenzione devono essere effettuate da personale qualificato ed esperto e nel pieno rispetto delle normative vigenti.
- Indossare indumenti e calzature antistatiche nel caso di intervento sulla scheda elettronica.
- Conservare queste avvertenze.
- Togliere sempre l'alimentazione elettrica durante le operazioni di pulizia o di manutenzione.
- Il prodotto deve essere destinato solo all'uso per il quale è stato espressamente studiato. Ogni altro uso è da considerarsi pericoloso.
- Il costruttore non può comunque essere considerato responsabile per eventuali danni derivanti da usi impropri, erronei ed irragionevoli.

- ⚠ Pericolo di esplosione se la batteria è sostituita con altra di tipo errato.
Le batterie, una volta esaurito il loro ciclo di vita, non devono essere gettate con i rifiuti indifferenziati, ma raccolte separatamente e avviate a corretto recupero.

Disinserimento di impianti Sicurezza

Premendo il tasto 8 è possibile disinserire le aree associate al trasmettitore (il LED 4 lampeggerà verde per 2 s).

Gestione di impianti Domotici B**CON L'INTERFACCIA OH/RXBD**

L'apprendimento del trasmettitore deve essere eseguito da PC con il software CAME D SW:

- da [RICERCA DISPOSITIVI] selezionare [PULS. DI APPRENDIMENTO] e premere il tasto 1 del trasmettitore per almeno 5 s. Il numero seriale e il modello del trasmettitore vengono visualizzati in [RICERCA DISPOSITIVI] 9.

FARE RIFERIMENTO AL MANUALE DEL SOFTWARE CAME D SW.

⚠ Requisiti richiesti: CAME D SW versione 1.4. e successive.

SENZA L'INTERFACCIA OH/RXBD

Per associare un tasto del trasmettitore all'uscita relè del modulo domotico, assicurarsi che il modulo sia in modalità apprendimento, e premere il tasto 1 del trasmettitore per almeno 5 s. Successivamente premere il tasto del trasmettitore da associare all'uscita relè domotica.

Funzionalità in modalità Domotica

L'attivazione dell'ingresso avviene tramite la pressione dei tasti 1/2/3/4 del trasmettitore.

Programmazione dei tasti del trasmettitore

Premere contemporaneamente i tasti 2 e 3 per almeno 6 s: i 4 LED si accendono a seconda della modalità di funzionamento impostata.

FISSO: modalità sicurezza (default);

LAMPEGGIO VELOCE: modalità domotica;

LAMPEGGIO LENTO: modalità ibrida (sicurezza/domotica).

Nel caso tutti i tasti siano configurati in modalità domotica, il tasto 8 assume la funzione di ingresso 4.

Per cambiare la modalità assegnata ad ogni tasto premere ripetutamente. A ogni pressione la modalità cambia in SICUREZZA-DOMOTICA-IBRIDO.

Premere il tasto 8 per uscire dalla programmazione, oppure attendere 1 m per uscire automaticamente.

Sostituzione della batteria C

Il prodotto è conforme alle direttive di riferimento vigenti.

Dismissione e smaltimento. Non disperdere nell'ambiente l'imballaggio e il dispositivo alla fine del ciclo di vita, ma smaltrirlo seguendo le norme vigenti nel paese di utilizzo del prodotto. I componenti riciclabili riportano simbolo e sigla del materiale.

I DATI E LE INFORMAZIONI INDICATE IN QUESTO MANUALE SONO DA RITENERSI SUSCETTIBILI DI MODIFICA IN QUALESiasi MOMENTO E SENZA OBBLIGO DI PREAVVISO. LE MISURE, SE NON DIVERSAMENTE INDICATO, SONO IN MILLIMETRI.

L'inserimento dell'impianto avviene tramite il lancio dei 3 scenari personalizzati associabili ai tasti 1/2/3 del trasmettitore.

Di default le associazioni tasto/scenario sono le seguenti:

- tasto 1 = scenario 1
- tasto 2 = scenario 2
- tasto 3 = scenario 3

Se lo scenario scelto prevede l'inserimento di una o più aree con tempo di uscita diverso da zero, è possibile azzerare le temporizzazioni premendo il tasto 1 per almeno 5 s, dopo l'avvio dello scenario stesso.

Premendo per almeno 5 s il tasto 8 si visualizza lo stato dell'impianto.

I LED segnalieranno una delle seguenti situazioni:

LED	Stato/Colore	Significato
1+4	Accesi/rosso	Scenario 1 attivo

ENGLISH

General warnings

- ⚠ Important personal safety instructions: READ CAREFULLY!
- Installation, programming, commissioning and maintenance must only be performed by qualified and experienced personnel in compliance with applicable regulations.
- Wear antistatic shoes and clothing if working on the control board.
- Keep hold of these warnings.
- Always disconnect the electrical power supply during cleaning or maintenance.
- This product should only be used for the purpose for which it was explicitly designed. Any other use is considered dangerous.
- The manufacturer declines all liability for any damage as a result of improper, incorrect or unreasonable use.
- ⚠ Risk of explosion if the battery is replaced with one of an incorrect type.
- Once flat, the batteries must not be thrown away with household waste but separated and recycled correctly.

Description

Two-way transmitter for controlling intrusion systems, home automation systems or both (hybrid). It allows the management of 3 inputs/scenarios programmed in the intrusion control unit.

Technical data

Type	PXWRC04
Power supply	1 x 3 V lithium battery (CR2032)
Frequency (MHz)	868.65
Max current draw (mA)	25
Radio power (dBm)	10
Battery life	2 years with 10 operations/day (at 20 °C)
Range with no obstacles (m)	100
Operating temperature (°C)	-5 to +55
Dimensions (mm)	38x76x9
EN 50131-5-3	

⚠ Normal key presses must last at least 1 second.

Intrusion system management A

Transmitter learning can take place in two ways:

- from a PC with the PXManager software by selecting [RADIOCOMMANDS] and entering the serial number ⑦ (shown on the label) in the [SERIAL] column ⑧.
- manually from a keypad, making sure that the intrusion control unit is in learning mode, pressing key 1 on the transmitter for at least 5 seconds.

REFER TO THE INTRUSION CONTROL UNIT INSTALLER MANUAL.

⚠ Requirements: PXC control unit with 1.0.18 firmware and later.

Features in Intrusion mode

The system is armed by launching the 3 customisable scenarios that can be associated with keys 1/2/3 on the transmitter.

The default key/scenario associations are as follows:

- key 1 = scenario 1
- key 2 = scenario 2
- key 3 = scenario 3.

If the chosen scenario involves the arming of one or more areas with an exit time other than zero, you can reset the timers by pressing key 1 for at least 5 seconds after launching the scenario itself.

Press ⑨ for at least 5 seconds to view the system status. The LEDs will indicate one of the following situations:

LED	Status/Colour	Meaning
①+④	On/red	Scenario 1 active
②+④	On/red	Scenario 2 active
③+④	On/red	Scenario 3 active
④	On/green	System totally disarmed

FRANÇAIS

Instructions générales

- ⚠ Instructions importantes pour la sécurité des personnes : À LIRE ATTENTIVEMENT !
 - L'installation, la programmation, la mise en service et l'entretien doivent être effectués par du personnel qualifié et dans le plein respect des normes en vigueur.
 - Porter des vêtements et des chaussures antistatiques avant d'intervenir sur la carte électronique.
 - Conserver ces instructions.
 - Toujours couper le courant électrique durant les opérations de nettoyage ou d'entretien.
 - Ce produit ne devra être destiné qu'à l'utilisation pour laquelle il a été expressément conçu. Toute autre utilisation est à considérer comme dangereuse.
 - Le fabricant décline toute responsabilité en cas d'éventuels dommages provoqués par des utilisations imprudentes, incorrectes et déraisonnables.
 - ⚠ Ne remplacer la pile usagée que par une pile compatible afin d'éviter tout risque d'explosion.
 - Ne pas jeter les piles à la poubelle au terme de leur cycle de vie, mais les collecter séparément en vue d'un recyclage correct.

Disarming intrusion systems

Press ⑨ to disarm the areas associated with the transmitter (LED 4 will flash green for 2 seconds).

Managing home automation systems B

WITH THE OH/RXBD INTERFACE

Transmitter learning must be carried out from a PC using the CAME D SW software:

- from [DEVICE DISCOVERY] select [SELF LEARNING BUTTON] and press the 1 key on the transmitter for at least 5 seconds. The serial number and transmitter model are shown in [DEVICE DISCOVERY] ⑨.

REFER TO THE CAME D SW SOFTWARE MANUAL

⚠ Requirements: CAME D SW version 1.4 and later.

WITHOUT THE OH/RXBD INTERFACE

In order to associate a transmitter key with the home automation module relay output, ensure that the module is in learning mode, and press key 1 on the transmitter for at least 5 seconds. Then press the key on the transmitter to be associated with the home automation relay output.

Features in Home Automation mode

The input is activated by pressing keys 1/2/3/4 on the transmitter.

Transmitter key programming

Press keys 2 and 3 at the same time for at least 6 seconds: 4 LEDs light up depending on the operating mode set.

STEADY: intrusion mode (default);

FAST FLASHING: home automation mode;

SLOW FLASHING: hybrid mode (intrusion/home automation).

If all the keys are configured in home automation mode, the ⑨ key takes on the role of input 4.

To change the mode assigned to each key, press it repeatedly. Each time the key is pressed, the mode changes: INTRUSION-HOME AUTOMATION-HYBRID.

Press ⑨ to exit programming, or wait 1 minute to exit automatically.

Replacing the battery C

The product complies with the applicable reference directives. Dismantling and disposal. Dispose of the packaging and the device properly at the end of its life cycle, according to the regulations in force in the country where the product is used. The recyclable components bear the symbol and code for the material. THE DATA AND INFORMATION PROVIDED IN THIS MANUAL ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT PRIOR NOTICE. MEASUREMENTS, UNLESS OTHERWISE INDICATED, ARE IN MILLIMETRES.

If the chosen scenario involves the arming of one or more areas with an exit time other than zero, you can reset the timers by pressing key 1 for at least 5 seconds after launching the scenario itself.

Press ⑨ for at least 5 seconds to view the system status. The LEDs will indicate one of the following situations:

LED	Status/Colour	Meaning
①+④	On/red	Scenario 1 active
②+④	On/red	Scenario 2 active
③+④	On/red	Scenario 3 active
④	On/green	System totally disarmed

FRANÇAIS

Instructions générales

- ⚠ Instructions importantes pour la sécurité des personnes : À LIRE ATTENTIVEMENT !
 - L'installation, la programmation, la mise en service et l'entretien doivent être effectués par du personnel qualifié et dans le plein respect des normes en vigueur.
 - Porter des vêtements et des chaussures antistatiques avant d'intervenir sur la carte électronique.
 - Conserver ces instructions.
 - Toujours couper le courant électrique durant les opérations de nettoyage ou d'entretien.
 - Ce produit ne devra être destiné qu'à l'utilisation pour laquelle il a été expressément conçu. Toute autre utilisation est à considérer comme dangereuse.
 - Le fabricant décline toute responsabilité en cas d'éventuels dommages provoqués par des utilisations imprudentes, incorrectes et déraisonnables.
 - ⚠ Ne remplacer la pile usagée que par une pile compatible afin d'éviter tout risque d'explosion.
 - Ne pas jeter les piles à la poubelle au terme de leur cycle de vie, mais les collecter séparément en vue d'un recyclage correct.

For details on scenarios and related areas associated with the transmitter, refer to the intrusion control unit installer manual.

The LED of the selected channel will remain on and steady for about 2 seconds to confirm that the intrusion control unit has received the command.

Disarming intrusion systems

Press ⑨ to disarm the areas associated with the transmitter (LED 4 will flash green for 2 seconds).

Managing home automation systems B

WITH THE OH/RXBD INTERFACE

Transmitter learning must be carried out from a PC using the CAME D SW software:

- from [DEVICE DISCOVERY] select [SELF LEARNING BUTTON] and press the 1 key on the transmitter for at least 5 seconds. The serial number and transmitter model are shown in [DEVICE DISCOVERY] ⑨.

REFER TO THE CAME D SW SOFTWARE MANUAL

⚠ Requirements: CAME D SW version 1.4 and later.

WITHOUT THE OH/RXBD INTERFACE

In order to associate a transmitter key with the home automation module relay output, ensure that the module is in learning mode, and press key 1 on the transmitter for at least 5 seconds. Then press the key on the transmitter to be associated with the home automation relay output.

Features in Home Automation mode

The input is activated by pressing keys 1/2/3/4 on the transmitter.

Transmitter key programming

Press keys 2 and 3 at the same time for at least 6 seconds: 4 LEDs light up depending on the operating mode set.

STEADY: intrusion mode (default);

FAST FLASHING: home automation mode;

SLOW FLASHING: hybrid mode (intrusion/home automation).

If all the keys are configured in home automation mode, the ⑨ key takes on the role of input 4.

To change the mode assigned to each key, press it repeatedly. Each time the key is pressed, the mode changes: INTRUSION-HOME AUTOMATION-HYBRID.

Press ⑨ to exit programming, or wait 1 minute to exit automatically.

Replacing the battery C

The product complies with the applicable reference directives. Dismantling and disposal. Dispose of the packaging and the device properly at the end of its life cycle, according to the regulations in force in the country where the product is used. The recyclable components bear the symbol and code for the material. THE DATA AND INFORMATION PROVIDED IN THIS MANUAL ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT PRIOR NOTICE. MEASUREMENTS, UNLESS OTHERWISE INDICATED, ARE IN MILLIMETRES.

If the chosen scenario involves the arming of one or more areas with an exit time other than zero, you can reset the timers by pressing key 1 for at least 5 seconds after launching the scenario itself.

Press ⑨ for at least 5 seconds to view the system status. The LEDs will indicate one of the following situations:

LED	Status/Colour	Meaning
①+④	On/red	Scenario 1 active
②+④	On/red	Scenario 2 active
③+④	On/red	Scenario 3 active
④	On/green	System totally disarmed

FRANÇAIS

Instructions générales

- ⚠ Instructions importantes pour la sécurité des personnes : À LIRE ATTENTIVEMENT !
 - L'installation, la programmation, la mise en service et l'entretien doivent être effectués par du personnel qualifié et dans le plein respect des normes en vigueur.
 - Porter des vêtements et des chaussures antistatiques avant d'intervenir sur la carte électronique.
 - Conserver ces instructions.
 - Toujours couper le courant électrique durant les opérations de nettoyage ou d'entretien.
 - Ce produit ne devra être destiné qu'à l'utilisation pour laquelle il a été expressément conçu. Toute autre utilisation est à considérer comme dangereuse.
 - Le fabricant décline toute responsabilité en cas d'éventuels dommages provoqués par des utilisations imprudentes, incorrectes et déraisonnables.
 - ⚠ Ne remplacer la pile usagée que par une pile compatible afin d'éviter tout risque d'explosion.
 - Ne pas jeter les piles à la poubelle au terme de leur cycle de vie, mais les collecter séparément en vue d'un recyclage correct.

For details on scenarios and related areas associated with the transmitter, refer to the intrusion control unit installer manual.

The LED of the selected channel will remain on and steady for about 2 seconds to confirm that the intrusion control unit has received the command.

Disarming intrusion systems

Press ⑨ to disarm the areas associated with the transmitter (LED 4 will flash green for 2 seconds).

Managing home automation systems B

WITH THE OH/RXBD INTERFACE

Transmitter learning must be carried out from a PC using the CAME D SW software:

- from [DEVICE DISCOVERY] select [SELF LEARNING BUTTON] and press the 1 key on the transmitter for at least 5 seconds. The serial number and transmitter model are shown in [DEVICE DISCOVERY] ⑨.

REFER TO THE CAME D SW SOFTWARE MANUAL

⚠ Requirements: CAME D SW version 1.4 and later.

WITHOUT THE OH/RXBD INTERFACE

In order to associate a transmitter key with the home automation module relay output, ensure that the module is in learning mode, and press key 1 on the transmitter for at least 5 seconds. Then press the key on the transmitter to be associated with the home automation relay output.

Features in Home Automation mode

The input is activated by pressing keys 1/2/3/4 on the transmitter.

Transmitter key programming

Press keys 2 and 3 at the same time for at least 6 seconds: 4 LEDs light up depending on the operating mode set.